

MITO




Installation instruction
spoiler "Trofeo"
for Alfa Romeo MiTo (all versions)

product number: 0100003030




plastic adhesive




cutting knife



tape



plastic cleaner



sanding paper

1

Required tools and materials (not included). Use a high elastic plastic adhesive suited for automotive applications like Betalink K1 or Sikaflex 221.

Paint instructions:

1. Clean the part with a plastics cleaner to remove any mold release agent.
2. Check for any imperfections, use filler to smooth the surfaces if necessary.
3. Roughen the surfaces of the parts using very fine sanding paper or a scuff pad.
3. Clean the abraded surfaces with a plastics cleaner.
4. Apply a plastics primer, let it air dry completely.
5. Apply the paint in several layers, followed by a layer of clear coat if applicable.
6. Let the paint air dry at room temperature.




Precautions:

- Use a paint that does not react with ABS plastic in any way, check the paint's specifications.
- ABS is a thermoplastic material that should not be heated, let the paint dry at room temperature
- Paint the parts in a dust free, well conditioned and ventilated environment.
- For best results paint the parts in a professional paintshop by a professional painter.
- These instructions are indicative, always refer to the product specifications of the chosen paint.




2

Paint the spoiler in the desired colour following these instructions and precautions.




3

Clean the indicated area of the front bumper thoroughly.



4

Sand and clean the indicated edge of the spoiler. Apply adhesive according to the product specifications and instructions. Firmly press the spoiler to the front bumper, clean any excessive adhesive instantly.



5

Use packaging and tape to apply constant pressure to the spoiler while the adhesive hardens. Do not put any tape on the spoiler itself. Let the adhesive harden completely before removing the tape.



12 Hours: do not move the car



24 Hours: do not drive the car fast



48 Hours: do not wash the car

6

Respect these precautions after fitting the bodykit to guarantee a solid fixing of the parts to the car.